

Heatec Pty Ltd. ACN 93 059 368 393. QLD Elec. Contractor's Licence No 7128 Unit 26, 17 Cairns St LOGANHOLME. QLD. 4129

Tel: 3806 2326

Fax: 3806 5457

Email: heatecsales@gmail.com

Termination requirements for bedded and thin bed floor heating

The chosen thermostat position should be exposed to the room conditions, avoiding cupboards, uninsulated external walls and where exposed to direct sunlight. In small rooms supply is normally taken from any existing circuit. For larger rooms or where a different tariff or home automation is used, run a separate circuit.

